




ALMH-00 - Mandril Hidraulico ALH







ITEM	DESCRIÇÃO	PN	QTD.
1	ALMH-01 - Cabeça do Mandril ALH	ALMH-01	1
2	ALMH-02 - Cilindro de Acionamento do Mandril ALH	ALMH-02	2
3	ALMH-03 - Desrosqueador Mandril ALH	ALMH-03	1
4	ALMH-04 - Par de Cilindros do Desrosqueador Mandril ALH	ALMH-04	1
5	PACE-M8X40	PACE-M8X40	16

ALMH-01 - Cabeça do Mandril ALH







ITEM	DESCRIÇÃO	PN	QTD.
1	ALMH-01-01 - Castelo do Mandril ALH	ALMH-01-01	1
2	ALMH-01-02 - Tampa do Castelo ALH	ALMH-01-02	1
3	ALMH-01-03 - Prato das Molas do Mandril ALH	ALMH-01-03	1
4	ALMH-01-04 - Corpo Cônico do Mandril ALH	ALMH-01-04	1
5	ALMH-01-05 - Redução do Mandril ALH	ALMH-01-05	1
6	ALMH-01-06 - Mola de Compressão	ALMH-01-06	17
7	ALMH-01-07 - Chaveta do Castelo do Mandril ALH	ALMH-01-07	1
8	Kit Rolamento^ALMH-01 - Cabeça do Mandril ALH	ALMH-01-08	1
8.1	ALMH-01-08-1 - Capa Externa do Rolamento ALH	ALMH-01-08-1	1
8.2	ALMH-01-08-2 - Capa Interna do Rolamento ALH	ALMH-01-08-2	1
8.3	ALMH-01-08-3 - Rolamento do Mandril ALH	ALMH-01-08-3	1
9-B	ALMH-01-09-B - Mordente BQ Mandril ALH	ALMH-01-09-B	5
9-N	ALMH-01-09-N - Mordente NQ Mandril ALH	ALMH-01-09-N	5
9-H	ALMH-01-09-H - Mordente HQ Mandril ALH	ALMH-01-09-H	5
10-B	ALMH-01-10-B - Anel Trava dos Mordentes - B	ALMH-01-10-B	1
10-N	ALMH-01-10-N - Anel Trava dos Mordentes - N	ALMH-01-10-N	1
10-H	ALMH-01-10-H - Anel Trava dos Mordentes - H	ALMH-01-10-H	1
11	PAST-01 - Pastilha LY	PAST-01	10
12	PACC-1-2"x2"-UNC	PACC-1-2"x2"-UNC	10
13	BGR-Ø1-4"-28FPP	BGR-Ø1-4"	3
14	PACC-M5X8	PACC-M5X8	2
15	MB-28 - Arruela Aranha Ø140	MB-28	1
16	KM-28 - Porca Tipo Aranha Ø140	KM-28	1
17	ORI-155x3.5	ORI-155x3.5	1




ALMH-02 - Cilindro de Acionamento do Mandril ALH





ITEM	DESCRIÇÃO	PN	QTD.
1	ALMH-02-01 - Camisa do Cilindro de Acionamento ALH	ALMH-02-01	1
2	ALMH-02-02 - Embolo Cilindro de Acionamento	ALMH-02-02	1
3	ALMH-02-03 - Haste Cilindro de Acionamento	ALMH-02-03	1
4	ALMH-02-04 - Cabeçote Cilindro de Acionamento	ALMH-02-04	1
5	ALMH-02-05 - Arruela Espaçadora do Cilindro de Acionamento	ALMH-02-05	1
6	ATE-35	ATE-35	1
7	Kit Reparo^ALMH-02 - Cilindro de Acionamento do Mandril ALH	KR-CA-MH	1
8	PSA-1.1-2"-UNF	PSA-1.1-2"-UNF	1
9	ORI-16x2.65	ORI-16x2,65	2
10	Adaptador 8 Jic	8MJ-8MB	2
11	T 8 Jic Femea Central	8MJ-8MJ-8FJ	1




ALMH-03 - Desrosqueador Mandril ALH






ITEM	DESCRIÇÃO	PN	QTD.
1	ALMH-03-01 - Suporte Fixo do Desrosqueador	ALMH-03-01	1
2	ALMH-03-02 - Suporte Movel do Desrosqueador	ALMH-03-02	1
3	ALMH-03-03 - Parafuso $\varnothing 1'' \times 3'' \times 8FPP$	ALMH-03-03	4
4	ALMH-03-04 - Mola Externa do Desrosqueador	ALMH-03-04	4
5	ALMH-03-05 - Guia da Mola Interna do Desrosqueador	ALMH-03-05	4
6	ALMH-03-06 - Guia dos Cilindros	ALMH-03-06	4
7	ALMH-03-07 - Mola Interna do Desrosqueador	ALMH-03-07	4
8	PACC-M8X20	PACC-M8X20	4



ALMH-04 - Par de Cilindros do Desrosqueador Mandril ALH



(62) 3877-1485


(62) 98190-1400

(62) 98118-1940

 Sondagyn.comercial01@gmail.com



Rua FL-01Qd.06 Lt.05, 632 Parque das Flores - Goiânia-GO



ITEM	DESCRIÇÃO	PN	QTD.
1	ALMH-04-01-E - Camisa Desrosqueador Hidraulico - Esquerda	ALMH-04-01-E	1
2	ALMH-04-01-D - Camisa Desrosqueador Hidraulico - Direita	ALMH-04-01-D	1
3	ALMH-04-02 - Embolo Cilindro do Desrosqueador	ALMH-04-02	2
4	ALMH-04-03 - Haste do Cilindro do Desrosqueador	ALMH-04-03	2
5	ALMH-04-04 - Cabeçote Cilindro do Desrosqueador	ALMH-04-04	2
6	ALMH-04-05 - Mordente Universal Cilindro do Desrosqueador	ALMH-04-05	2
7	Kit Reparo^ALMH-04 - Par de Cilindros do Desrosqueador Mandril ALH	KR-CD-MH	2
8	ATE-35	ATE-35	2
9	PAST-01 - Pastilha LY	PAST-01	20
10	PACC-M10X70	PACC-M10X70	2

(62) 3877-1485

(62) 98190-1400

(62) 98118-1940

 Sondagyn.comercial01@gmail.com



Rua FL-01Qd.06 Lt.05, 632 Parque das Flores - Goiânia-GO

